



RENTAL IN/OUT CHECKLIST

Made in America Since 1968

5700

5700DL, 5700-HER, 5700-SUN, 5700DL-HER, 5700HS



Each time the 5700 is rented out and returned, follow these steps to ensure it is in proper working condition.

Before conducting any maintenance procedures, make sure you are wearing proper safety equipment and the machine is disconnected from power.

**Refer to Service Manual for precise schedule*

- Read the manual before operating the machine.
 - Check to ensure the 7 foot 12 gauge charging cord is with the machine and in good, working condition.
 - Verify the 70 amp circuit breaker is working and in the "On" position. (1)
 - Verify the 48-volt blue plugs are firmly connected. (2)
 - Ensure the seat is securely fastened to the machine. The seat has a safety switch. The operator must be properly seated for machine to run.
 - Sit on the machine. Release the E-Stop. For domestic machines, push the green "ON" button to start the machine. For international machines, turn the key switch.
 - Push the E-Stop button to ensure the machine stops running. Then twist the button to the "up" position to ensure it releases properly.
 - With the machine off, make certain the control levers are working properly and return freely to the center position when not being engaged by the operator.
 - Check that the backup beeper is working.
 - Check hydraulic fluid level.
 - Remove filler plug located in front of right, rear tire.
 - Hydraulic fluid should be visible 1" below hole.
 - Reinsert filler plug.
 - Keep fittings and hoses tight. If a leak is noticeable, re-tighten fitting. If leakage persists, remove the connection and inspect. **Caution:** Never check for hydraulic leaks while machine is running.
 - To adjust the manual slide plate, insert a cutting head into the machine. Make sure machine is resting on front caster. Completely loosen slide plate bolts. Use cylinder lift lever to raise or lower machine to move slide plate up or down. Make sure to keep all appendages away from pinch or crush points.
 - Remove any glue, mastic, and debris from the wheels, debris deflector, and cutting head.
 - Look for damage to the cutting head.
- Clean out dust and debris from motor cover/housing.
 - All maintenance, nameplates and safety stickers must be in place and legible.
 - Charge to 5700:
 1. Plug in the charger using the provided extension cord.
 2. Charger will self test.
 3. Confirm there is a flashing amber light indicating the charger is plugging into the proper voltage.
 4. Confirm on of the amber "Current Output" lights is solid, indicating the charger is operating properly.
 - Make sure the operator's manual is with the machine.