



Made in America Since 1968

MAINTENANCE CHECKLIST

HELIX®

HELIX-HER, HELIX-SUN

Before conducting any maintenance procedures, make sure you are wearing proper safety equipment and the machine is disconnected from power.

*Refer to [Service Manual](#) for precise schedule



WEEKLY RECOMMENDED MAINTENANCE

- Check that all screws are tight and secure.
- Check that tooling plate is secure and free of damage.
- Check that satellites are free of damage and rotate freely.
- Vacuum excess dust from under machine.
- Inspect brush at base of metal dust shroud.
- Check handle position operation.
- Check cam levers for proper handle securing.

QUARTERLY RECOMMENDED MAINTENANCE*

* More frequently if rented regularly

- Clean dust and debris from the inside of the deck area being careful to collect large amounts with your dust collector.
- Verify that the deck is spinning and satellites rotate freely.
- Turn the machine on and pull the safety lanyard to ensure the machine stops running. Turn the machine off and replace the lanyard.
- All maintenance, nameplates and safety stickers must be in place and legible
- Remove any glue, mastic and debris from the wheels
- Check that the power cord is free of damage
- Check that motor power cord and twist lock plug are free of damage



SCAN TO ACCESS YOUR MANUAL