



Made in America Since 1968

MAINTENANCE CHECKLIST

DL2000

Before conducting any maintenance procedures, make sure you are wearing proper safety equipment and the machine is disconnected from power.

**Refer to [Service Manual](#) for precise schedule*



WEEKLY RECOMMENDED MAINTENANCE

- Check for misaligned, binding of moving parts, broken parts and any other conditions that may affect operation.
- Check that all screws are tight and secure
- Check to see whether the filter is worn or clogged.
- Check all seals for indication of leaks or wear.
- Make sure the Longopac is empty and enough remains for upcoming jobs. Verify zip ties and knife for the Longopac are present.
- Inspect the hose for cracks or leaks.
- Ensure the flap to purge the dust collector is free of damage and returns to the closed position when released.
- Verify the power cord is free of damage and connections are secure.
- Release the red knob on the machine's vertical support. Using the black handle, lift and lower the machine. Ensure the machine locks into the operating and transport positions and slides freely.



**SCAN TO
ACCESS
YOUR
MANUAL**